



Assembly Guide

A-HUB1-1 Inline USB Hub

Copyright © Topaz Systems Inc. All rights reserved.

For Topaz Systems, Inc. trademarks and patents, visit www.topazsystems.com/legal.

Table of Contents

Overview.....	3
Assembly Instructions For Signature Pad Connection.....	3
Assembly Instructions For Flash Drive Connection	4

Overview

With the Topaz Inline USB 3.0 Hub (model A-HUB1-1), users can house their high-speed flash drive containing *Windows To Go* and all necessary files to run the application software, as well as connect their Topaz signature pad.

Some of the Topaz Inline USB Hub benefits include:

1. The user's flash drive cannot get lost, stolen, or separated from the signature pad, as it is completely enclosed in the USB Hub.
2. The user's flash drive is protected from possible damage inside the USB Hub housing.
3. As the user's flash drive naturally heats up during use, the Topaz A-HUB1-1 contains the heat away from the user.
4. If the computer being used has only one USB port available, the Topaz A-HUB1-1 allows both the flash drive and the signature pad to be connected to a single port.

By using only one USB port, the A-HUB1-1 allows for improved field support and maintenance. In addition, it provides a complete, integrated, one-part solution for deploying *Windows To Go*.

Assembly Instructions For Signature Pad Connection

NOTE: Power should always be off during assembly. Please remove the USB cable from the computer before installing a thumb drive or connecting the USB cable of a signature pad. Take care to perform these steps in a clean, static-free environment. During assembly, do not touch any of the sensitive electronic components or circuit traces.

- 1) Plug your signature pad into the open end of the A-HUB1-1.



- Put the curved side cover (included) over the cable to secure it in place.



- Insert two screws (included), and tighten.



Assembly Instructions For Flash Drive Connection

- Plug in the *Windows To Go* flash drive.



- Snap on the USB Hub cover (included). Note that the cover may seem to fit on either way; however, it will only fit snug and snap on one way (see below for image).

- 3) Insert four screws (included), and tighten.



- 4) Your A-HUB1-1 is now ready for use (shown below with T-LBK462 model).

